



### **IMPORTANT! READ THIS FIRST**

Installation of shock absorbers requires special tools and expert knowledge. Accordingly, installation of all BILSTEIN products must be performed by a qualified suspension specialist.

Always use a chassis hoist for the installation of BILSTEIN products and make certain that the raised vehicle is securely attached to the hoist and/or supported to prevent the vehicle from slipping, falling, or moving during the installation process.

**If you choose to install any BILSTEIN product without the necessary special tools, expertise or chassis hoist, you may subject yourself to the risk of serious bodily injury or death.**

**If you elect not to use a chassis hoist please observe the following precautions:**

- Make sure the vehicle is on level ground
- That all tires on the ground during installation are blocked to prevent movement
- That at least two tires are on the ground at all times
- That adequately secured safety stands (jack stands) are used to support the chassis
- **NEVER** get under the vehicle until you have checked to make sure all of these steps are performed